



WunderWall Installation Guide

1 Before You Begin:

Bring your WunderWall graphic inside to acclimate for a minimum of 24 hours before beginning installation. It's also a good idea to roll out the panels to lay flat for a few hours so they can relax.

We recommend clearing the room of any furniture and cleaning your wall surfaces with a rag or towel. **See our included cleaning instructions for more details on cleaning and wall preparation.**

Turn off the circuit breakers for safety and remove any light or plug plates from your walls.

REQUIRED TOOLS:

 Phillips screwdriver

 Pencil

 Level

 Tape measure

 Utility knife

2 Confirm Details



After confirming the wall size, compare it to the size shown on the assembly guide. Verify panel sizes against the assembly guide before beginning installation.

All WunderWall graphics have tape marks indicating where they meet the adjacent panels. Use these as a suggestion, not a rule. Always confirm art alignment during install.

3 Make Reference Marks



Measure the width of your left panel and **subtract half an inch**. Use this measurement to make a pencil reference mark on the wall. This will allow the left panel to have half of an inch overhang along the left side to trim off later.

From your reference mark, make a few additional marks down the wall with a level. This will ensure the first panel is straight.

4 Remove precut liner strip



Remove the precut strip from the back of the first panel. You'll find it near the top.



WunderWall Installation Guide

5 Line up your first panel



Line up the edge of the first panel with the pencil marks made earlier. Double check by moving panel until graphic lines up from top to bottom.

Once straight, use the squeegee to apply the small strip on the first panel.

6 Install the first panel



Now that the small strip is attached to the wall, peel off the liner of the top section and apply the graphic using the squeegee from the bottom up. Work out from the center of the panel.

WunderWall graphics can be pulled up and reapplied to fix any bubbles or wrinkles.

7 Complete the first panel




Tuck edges and corners in well with the edge of the squeegee. Work your way down the panel by peeling off the liner in small sections (not all at once).

Using a sharp blade, trim off excess. Use a straight edge to help if necessary.

Excess should peel off neatly and easily.

Edges can be trimmed off after each panel goes up, or all at once when finished.

8 Trim around switches & plugs



With the power still off, cut around switches and plugs, being careful not to cut beyond plate area.



WunderWall Installation Guide



9 Align remaining panels



Align next panel using tape as guides.
Continue installation across wall until all panels are installed.
Remove tape tabs.

10 Enjoy!



Sit back and enjoy your new WunderWall graphic!



WunderWall Cleaning & Preparation

Wall Preparation

Preparing your wall for your new WunderWall mural will make installation easier and will contribute to the longevity of your mural. We recommend that your wall is as smooth as possible and doesn't have any holes, scratches, or textures. It's best to wipe down your walls with a soft damp rag to remove any dust or other debris that might exist.

Freshly Painted Walls

If your wall has been freshly painted, the paint will need time to cure before your WunderWall mural can be installed. We recommend waiting 2 days (48 hours) if your wall has been primed and waiting a full 2 weeks if your wall has been painted using paint or a primer + paint combination. This gives the paint or primer time to let off any gasses that it needs to release that would create bubbles under your wall mural.

For best results avoid the following:

- Flat matte painted surfaces
- Paint containing waxes or silicone
- Textured surfaces/paint
- Latex paint applied to wood
- Oil alkyd primers & enamels (slow drying)
- Low-VOC paints
- Wallpaper

